



Mood Bluetooth True Wireless Earphones
TLL511331
User Manual



INTO YOUR FUTURE



Thank you for choosing us!

Please read this User Manual carefully and keep it for future references.

Before using the earphones, fully charge their battery and connect them with a compatible phone.



Description and accessories



S



M



L

This product is equipped with different types of earmuffs. Please choose the appropriate earmuffs.

Operating instructions.

● Charging the earphones

During using, when the red light flashes to indicate that the power of the earphones is too low, charge the earphones. Put the earphones into the charging case; the charging time is about 1.5 hours and the red light of the earphone will be on when charging. When fully charged, the blue light will be on and will automatically turn off after 5 seconds.

● Charging the case

The red light will be on during charging and will turn blue once the case will be fully charged. A full charge cycle takes about 3 hours.



Battery capacity:

5V 35mAh (Earphones)


5V 420mAh (Charging case)

●Warning: The rechargeable battery of this product must be disposed properly for recycling. Please do not put the battery into a fire to avoid an explosion. It is recommended that lithium batteries be charged every three months if not used.

●Power on or off

●Power on: Take out the earphones from the charging case and they will automatically turn on.

●Power off: Put the earphones back into the charging case and they will automatically shut down.



Connection:

The earphones enter TWS pairing mode automatically when taken out of their charging case. If the earphones don't enter pairing mode automatically, press the MFB (multifunctional button) once.

Functions:

- Answer incoming call: Short press the MFB to answer the call.
- Siri/Voice dialing: Once the earphones are paired, hold the MFB for 2s, then release the button.
- Reject incoming call: Hold the MFB button for 1s, then release the button.
- Cancel dialing: While calling, press the MFB once to cancel the dialing.
- End call: Press the MFB once to end the call.
- Pause music: While playing music, click the MFB to pause playback.
- Play music: While music is paused, click the MFB to restart playback.
- Previous song: While playing music, press the left or right earphone's MFB three times to go to previous song.

- Next song: While playing music, double-click the left or right earphone's MFB to switch to the next song
- Automatic reconnection: Once powered on, the earphones will automatically reconnect to the last paired phone.

Clear pairing information

With the earphones in pairing mode, quickly press the MFB three times and hold for 5 seconds after the third press. Turn off and back on the earphones. Now pairing history has been cleared.

Please follow the company's usage regulations. The damage caused by incorrect use will invalidate the product's warranty

■ Maintenance

Please follow these suggestions to help you comply with the warranty and extend the life of the product.

- Keep the product dry and do not put it in a damp place to avoid affecting the internal circuitry of the product.
- Do not put the product in a place where the sun is shining or where the temperature is high. High temperatures can shorten the life of electronic components, damage batteries, and deform some plastic parts.
- Do not put the product in a cold place to avoid damaging the internal circuit board.
- Do not attempt to disassemble the product. If you are not a professional, you may damage the product.
- Do not drop, strongly vibrate, or hit the product with a hard object to avoid damaging internal circuits.
- Do not use harsh chemicals or detergents to clean the earphones.
- Do not use sharp objects on the surface of the product to avoid damage to the outer casing and affect the appearance. If the product does not work properly, please send it to your qualified service point and the staff will be happy to help you solve the problem.

Disposal and recycling information



The crossed-out wheeled-bin symbol on your product, battery, literature or packaging reminds you that all electronic products and batteries must be taken to separate waste collection points at the end of their working lives; they must not be disposed of in the normal waste stream with household garbage. It is the responsibility of the user to dispose of the equipment using a designated collection point or service for separate recycling of waste electrical and electronic equipment (WEEE) and batteries according to local laws.

Proper collection and recycling of your equipment helps ensure EEE waste is recycled in a manner that conserves valuable materials and protects human health and the environment, improper handling, accidental breakage, damage, and/or improper recycling at the end of its life may be harmful for health and environment.



ABN Systems International

-  Str. Marinariilor, nr.29
Sector 1, Bucuresti, Romania
-  004,021,233,09,95
-  office@tellur.com
office@abnsystems.ro
-  www.tellur.com