



Magnetic Qi Wireless Car Charger Mount TLL151091 User Manual



Thank you for choosing a Tellur product! The wireless charger magnetic holder is a very convenient device, with unique magnetic mount design. By simply placing your phone on the magnetic holder the charging function becomes active. It can be easily installed in the air vent or on a plane surface (using the adhesive cradle provided) becoming a perfect car holder for your phone. Please read the user manual before using and keep it for future reference.

PRODUCT COMPONENTS



How to use it:

1. Air vent mount installation
Clamp the bracket to the air conditioning vent in the car, connect the USB power cable, adjust the angle.
2. Charging
- For mobile phone with wireless charging function the charger is ready for use out of the box (***)In general, the induction area is located on the back of the phone, center position).
- Mobile phone without wireless charging function needs to have the induction device installed first (***)not included)

Technical Specifications

Model: TLL151091
Input: DC 5V/2A
Output: DC 5V/1.5A (MAX)
Dimension: 65mm (Φ) 55mm (H)
Weight: 90g
Certificate: Qi

Safety instructions

1. Do not disassemble or throw into fire or water, to avoid causing a short circuit leakage.
2. Do not use wireless charger in severely hot, humid or corrosive environments, to avoid circuit damage and occurs leakage phenomenon.
3. Do not place too close to objects with magnetic stripe or chip card

(ID card, bank cards, etc.) to avoid magnetic failure.
4. Please keep the distance at least 20cm between implantable medical devices potential interference with the medical device.
5. This product is not a toy, keep away from the reach of children, to avoid unnecessary.

Notes

1. Please use an AC Adapter with real 2A output. The input of the wireless charger is DC 5V/2A, insufficient input current may affect the efficiency or cause unstable charging.
- 2.The coils were embedded in the middle of the wireless charging magnetic holder. It can charge all Qi mobile devices. However, sometimes, the receiver coil in your phone is at the bottom and you must adjust the position of your phone to get it charged.
3. Some mobile phone respond a little slower when put on the wireless charging magnetic holder, this is usually due to the operating system used.

FAQ and Solution

- 1.Why the LED indicator keeps flashing and my phone does not receive any power?
-Please make sure your mobile device is Qi-Standard supported.
-Make sure you find the right charging position.
-Make sure you use an AC adapter with full 2A output.



Incarcator Auto Wireless Qi Magnetic TLL151091

Manual de utilizare



Va multumim ca ati ales un produs Tellur! Suportul magnetic cu incarcare fara fir este un dispozitiv de masina foarte convenabil, cu un design magnetic unic. Pur si simplu plasand telefonul pe suportul magnetic, acesta incepe sa se incarce. Este usor de instalat in grila de ventilatie a masinii sau pe o suprafata plana (cu adaptorul adeziv inclus in pachet), devenind un suport perfect pentru telefon. Cititi manualul de utilizare inainte de a utiliza produsul si pastrati-l pentru recomandari ulterioare.

COMPONENTELE PRODUSULUI



Cum se foloseste

1. Instalarea suportului in masina
Fixati clapeta de prindere la grila de ventilatie a aerului conditionat sau in alte locuri din masina, conectati la cablul de alimentare USB si reglati unghiul.
2. Incarcarea
- Pentru telefoanele mobile cu functie de incarcare wireless incorporata acest incarcator este gata de folosire direct in cutie. (***)In general, zona de inductie este localizata pe spatele telefonului in zona centrala.).
- Pentru telefoanele mobile care NU au functia de incarcare wireless incorporate, trebuie sa montati mai intai un adaptor pentru incarcare fara fir (***)nu este inclus)

Specificatii tehnice

Model: TLL151091
Intrare: DC 5V/2A
Iesire: DC 5V/1.5A (MAX)
Dimensiune: 65mm (Φ) 55mm (H)
Greutate: 90g
Certificari: Qi

Instructiuni de siguranta

1. Nu dezasamblati sau aruncati in foc sau apa, pentru a evita un scurt circuit sau scurgeri.
2. Nu utilizati incarcatorul fara fir in medii foarte fierbinti, umede sau

corozive pentru a evita deteriorarea circuitului si preveni fenomenul de scurgere.
3. Nu lasati in apropiere obiecte cu banda magnetica sau cu cip (carte de identitate, carduri bancare etc.) pentru a evita demagnetizarea.
4. Tineti distanta de cel putin 20 cm intre dispozitivele medicale implantabile interferenta potential cu dispozitivul medical.
5. Acest produs nu este o jucarie, a nu se lasa la indemana copiilor, pentru a evita accidentele inutile.

Nota

1. Va rugam sa folositi un adaptor de bricheta cu o putere de iesire reala de 2A. Puterea necesara pentru incarcatorul fara fir Tellur este 2A, curentul de intrare insuficient poate scadea eficienta sau poate cauza instabilitate in incarcare.
2. Bobinele de inductie au fost incorporate in mijlocul suportului magnetic de incarcare fara fir. Cu toate acestea, uneori, bobina receptorului din telefon este in partea inferioara si trebuie sa reglati pozitia telefonului pentru a activa incarcarea.
3. Unele telefoane mobile raspund mult mai incet cand sunt puse pe suportul magnetic de incarcare fara fir, acest lucru se datoreaza in mod normal sistemului de operare folosit.

Intrebări si răspunsuri

- 1.De ce indicatorul LED continua sa clipeasca si telefonul meu nu primește nicio alimentare?
- Asigurați-va ca dispozitivul dvs. mobil este compatibil cu Qi-Standard.

2.Why it charges slower than my original adapter that comes with the mobile device?

- Check if the car lighter adapter offers sufficient power, min 2A.
 - Check the active apps on the phone. Some apps drain the power of the phone, affecting the efficiency of the charger.
3. Is radiation form wireless charging harmful to one's health?
The Tellur wireless charger emits non-ionizing radiation which is not harmful to humans.
- 4.My device is hot while charging, is it normal?
It depends on the receiver in your phone. If the charging coil of the receiver in your phone is small, the heat dissipation may not be good, and it makes your phone hot during charging.

Disposal and recycling information



The crossed-out wheeled-bin symbol on your product, battery, literature or packaging reminds you that all electronic products and batteries must be taken to separate waste collection points at the end of their working lives; they must not be disposed of in the normal waste stream with household garbage. It is the responsibility of the user to dispose of the equipment using a designated collection point or service for separate recycling of waste electrical and electronic equipment (WEEE) and batteries according to local laws. Proper collection and recycling of your equipment helps ensure EEE waste is recycled in a

a manner that conserves valuable materials and protects human health and the environment, improper handling, accidental breakage, damage, and/or improper recycling at the end of its life may be harmful for health and environment.

ABN Systems International

- Str. Marinarilor, nr.29
Sector 1, Bucuresti, Romania
- 004.021.233.09.95
- office@tellur.com
office@abnsystems.ro
- www.tellur.com



• Materialele si componentele folosite la constructia acestui produs sunt materiale de inalta calitate, care pot fi refolosite si reciclate.
• Nu aruncati produsul impreuna cu gunoiul menajer sau cu alte gunoaie la sfarsitul duratei de exploatare.
• Transportati-l la centrul de colectare pentru reciclarea echipamentelor electrice si electronice unde va fi preluat in mod gratuit.
• Va rugam sa luati legatura cu autoritatile locale pentru detalii despre aceste centre de colectare organizate de operatori economici autorizati pentru colectarea DEEE.

ABN Systems International

- Str. Marinarilor, nr.29
Sector 1, Bucuresti, Romania
- 004.021.233.09.95
- office@tellur.com
office@abnsystems.ro
- www.tellur.com

