




Callisto Bluetooth Speaker

TLL161031/TLL161041

A silhouette of a city skyline with various skyscrapers, positioned at the bottom of the page.

INTO YOUR FUTURE

Product Presentation



Function Play/Pause/Phone
Volume / Previous Volume / Next



SD card
USB port On/Off Charging port
Micro USB

1. Bluetooth Mode

1.1 Bluetooth version:V4.2/

Suports HSP, HFP, A2DP, AVRCP protocol, English voice reminder.

Bluetooth paring name: Callisto

1.2 Toggle the ON/OFF button to turn on the speaker, then blue color Bluetooth LED indicator will light on, with notification voice to show you that bluetooth is ready. When Bluetooth LED light flashes use your device to search "Callisto" to connect and pair. After connected the blue LED indicator light will be on and the paired notification sound will be heard. When music is playing, the blue LED indicator will flash slowly. Once the device is paired this will connect automatically.

1.3 When music is played by Bluetooth mode, you can pick up your incoming call, speaker will stop play music and will enter voice call mode automatically.

1.4 When you disconnect the Bluetooth, a notification sound wil be heard and the speaker will enter in searching mode.

1.5 Long press the Volume +/- to turn up/down the volume. Short press for Next/Previous track.

2. Micro SD card Mode

- 2.1 When the Micro SD card is inserted the speaker will enter automatically in MicroSD card Mode.
- 2.2 When playing music the LED indicator will flash slowly.
- 2.3 Once you remove the micro SD card the speaker will enter the Bluetooth mode.
- 2.4 Switch to another mode by pressing the M button.

3. USB stick Mode

- 2.1 When the USB stick is inserted the speaker will enter automatically in MicroSD card Mode.
- 2.2 When playing music the LED indicator will flash slowly.
- 2.3 Once you remove the USB stick the speaker will enter the Bluetooth mode.
- 2.4 Switch to another mode by pressing the M button.

4. AUX MODE

- 4.1 Connect the speaker to Micro USB cable and your smartphone or other device to 3.5mm jack to play music.
- 4.2 When playing music the LED indicator will flash slowly.
- 4.3 Unplug the Micro USB to USB/3.5mm cable in the default AUX mode. Switch to the wanted mode if you need other functions.

5. FM MODE

5.1 When switch to FM mode, please insert the Micro USB cable as antenna. When listening the FM, you can press the play button to enter the automatically searching channel mode.

5.2 After the searched channel is saved, short press the +/- button to adjust the frequency and long press the +/- button to adjust the volume.

5.3 You can switch to another playing mode by pressing the M button.

6. Charging

6.1 Use the micro USB power cable to connect the speaker to a PC/charger with an USB port.

6.2 When charging a red indicator LED will light on.

6.3 When charge is full, the LED light will turn off.

6.4 When battery power is at a low level, a warning sound will be heard and the speaker will POWER OFF automatically.

7. BUTTONS FUNCTIONS

No.	BUTTON	MODE			
		BLUETOOTH	TF CARD / U DISK	AUX	FM
1	PLAY/STOP/HANDS FREE CALL	SHORT PRESS PLAY/STOP/HANDS FREE CALL	SHORT PRESS PLAY/STOP	SHORT PRESS PLAY/STOP	SHORT PRESS ENTER FM SEARCHING AUTOMATICALLY
2	NEXT/VOLUME+	SHORT PRESS NEXT/LONG PRSS VOLUME+	SHORT PRESS NEXT/LONG PRSS VOLUME+	SHORT PRESS INVALID / LONG PRESS VOLUME+	SHORT PRESS SWITCH CHANNEL/ LONG PRESS VOLUME +
3	PREVIOUS /VOLUME-	SHORT PRESS PREVIOUS/LONG PRSS VOLUME-	SHORT PRESS PREVIOUS /LONG PRESS VOLUME-	LONG PRESS VOLUME-	SHORT PRESS SWITCH CHANNEL/ LONG PRESS VOLUME-
4	SWITCHING MODE	SHORT PRESS FOR SWITCHING MODE			
5	POWER ON/OFF	POWER ON/OFF			

Technical specs

BT version: 4.2

Working range: 10m

Hands-free call: yes

FM radio: yes

MicroSD card port: yes

USB port: yes

Music playing time: up to 4 hours

Rated power: 3W

Battery: 400mAh

Device size: 112 x 42 x 82mm

Device weight: 190g

Colors: black, red

Package includes:

1 x Callisto Bluetooth speaker

1 x Micro USB – USB/3.5mm jack cable

1 x User manual

DISPOSAL AND RECYCLING INFORMATION



The crossed-out wheeled-bin symbol on your product, battery, literature or packaging reminds you that all electronic products and batteries must be taken to separate waste collection points at the end of their working lives; they must not be disposed of in the normal waste stream with household garbage.

It is the responsibility of the user to dispose of the equipment using a designated collection point or service for separate recycling of waste electrical and electronic equipment (WEEE) and batteries according to local laws. Proper collection and recycling of your equipment helps ensure EEE waste is recycled in a manner that conserves valuable materials and protects human health and the environment, improper handling, accidental breakage, damage, and/or improper recycling at the end of its life may be harmful for health and environment.