




Bluetooth Speaker 3W

TLL161231- User guide



INTO YOUR GREEN FUTURE

Thank you for choosing Tellur!

Please read this user manual carefully before using the product and keep it safe for future references. Please note! Damages caused by misuse of the product will not be covered by the product's warranty.

Technical specifications

BT version: 5.0

Working range: 10m

Hands-free call: yes

Music playing time: up to 2 hours

Rated power: 3W

Frequency response: 80HZ-18KHZ

Impedance: 4Ω

Signal-to-Noise ratio: 95dB

Charging time: 2 hours


Charging plug: Micro USB

Charging voltage: DC 5V

Battery: 300mAh Li-Polymer

Material: Wheat straw fiber 35% + 65% ABS

Product diagram



- 1.Power ON/OFF button – long press to activate.
- 2.Play/Pause button – short press to activate
- 3.Answer/End call button – short press to activate
- 4.Next song / Volume up button – short press for next song, long press for volume up
- 5.Previous song / Volume down button – short press for previous song, long press for volume down.
- 6.Charging LED indicator
- 7.Micro USB charging port
- 8.Speaker

Instructions

1. Turn the speaker on, the LED indicator will flash Blue.
2. Turn on Bluetooth function on mobile device, search for Tellur speaker and click pair.
3. Speaker will automatically pair to the last known mobile device.

Remarks:

1. When playing music, if the speaker turns off it means the battery's power is insufficient. Please fully recharge the speakers and then turn it back on.
2. When in BT mode, if the speaker does not work well, it might be because the Bluetooth device is out of range.
3. If you can not connect via Bluetooth, please check if the speaker is in the BT mode. If so, please restart the speaker.

Attention:

1. Use this device in a normal environment with a normal temperature.
2. Do not use the speaker in a wet environment.
3. Prevent the device from falling and avoid damages.
4. Do not dismantle or repair the speaker by yourself.
5. Do not throw the speaker into the fire – it has a built-in battery.

Disposal and recycling information



The crossed-out wheeled-bin symbol on your product, battery, literature or packaging reminds you that all electronic products and batteries must be taken to separate waste collection points at the end of their working lives; they must not be disposed of in the normal waste stream with household garbage.

It is the responsibility of the user to dispose of the equipment using a designated collection point or service for separate recycling of waste electrical and electronic equipment (WEEE) and batteries according to local laws.

Proper collection and recycling of your equipment helps ensure EEE waste is recycled in a manner that conserves valuable materials and protects human health and the environment, improper handling, accidental breakage, damage, and/or improper recycling at the end of its life may be harmful for health and environment.