









**10000mAh power bank,  
USB-C + Lightning cables built-in,  
QC3.0, PD3.0**

**TLL158441-TLL158451**

-  Installation guide and operation instructions
-  Ghid de instalare și instrucțiuni de funcționare
-  Guía de instalación e instrucciones de funcionamiento
-  Guide d'installation et mode d'emploi
-  Guida all'installazione e istruzioni per l'uso
-  Einbauanleitung und Bedienungsanleitung



**INTO YOUR FUTURE**

## Thank you, for choosing Tellur!

Please read this user manual carefully before using the product and keep it safe for future references.

**Please note!** Damages caused by misuse of the product will not be covered by the product's warranty.

## Technical specifications

Battery: Li-polymer

Capacity: 10000mAh/38.5Wh (3.85V)

Material: Aluminum alloy and plastic

Type-C input (PD 3.0): 5V/3A, 9V/2A, 12V/1.5A (18W)

Integrated USB-C cable output: 5V/3A, 9V/2A, 12V/1.5A, 10V/2.25A (22.5W)

Integrated Lightning cable output: 5V/2.4A, 9V/2.22A (20W)

USB output (QC3.0): 5V/3A, 9V/2A, 12V/1.5A, 10V/2.25A (22.5W)

Total power output: 22.5W

Rapid recharge time: 3-4H with 18W Power Delivery charger + Type-C to Type-C Cable (not included)

Protection functions: Short-circuit, overcharge, over discharge, overcurrent

Features: Battery level LED indicator, rapid recharge, Huawei Supercharge (22.5W), pass-through charging

Dimensions: 105 x 67.2 x 19.8mm

Weight: 198g

Color: TLL158441 Purple, TLL158451 Yellow

Compatibility: Universal

Compatible PD devices: iPad Pro 12.9", iPad Pro 10.5", iPad Pro 11", iPhone 15/ 15 Plus/ 15 Pro/ 15 Pro Max, iPhone 14/ 14 Plus/ 14 Pro/ 14 Pro Max, iPhone 13/ 13 Pro/ 13 Pro Max/ 13 Mini, iPhone 12/ 12 Pro/ 12 Pro Max/ 12 Mini, iPhone 11/ 11 Pro/ 11 Max/ XR/ X/ XS Max/ XS/ 8 Plus/ 8, Samsung S23 Ultra/ S23+/ S23, Samsung S22 Ultra/ S22+/ S22, Samsung S21+/ S21, Samsung S20 Ultra/ S20+ /S20, Samsung S10+/ S10/ S10e, Google Pixel 6 Pro/ 6, Google Pixel 5, Google Pixel 4 XL/ 4/ 3a XL/ 3a/ 3 XL/ 3

Package includes:


1 x 10000mAh power bank

1 x USB - USB-C,

1 x Manual

## Product diagram


EN



- 1.Power Button(ON/OFF)
- 2.Type-C Port
- 3.USB-A Port
- 4.Integrated Type-C Cable
- 5.Integrated Lightning Cable
- 6.Fast Charging/Discharging Indicator (Green LED)
- 7.Battery Indicator White LED)
- 8.Battery Indicator White LED)
- 9.Battery Indicator White LED)
- 10.Battery Indicator White LED)

## Power display light

Battery Level	LED 1 (⑦)	LED 2 (⑧)	LED 3 (⑨)	LED 4 (⑩)
75%-100%	On	On	On	On
50%-75%	On	On	On	Off
25%-50%	On	On	Off	Off
5%-25%	On	Off	Off	Off
1%-5%	Flicker	Off	Off	Off
0%	Off	Off	Off	Off

 LED indicators are divided into power indicator and charging indicator.

### Power indicator

Charge the power bank			
Display	Indicator light	Capacity percentage	Note
The first light flashes	○ ○ ○ ○	0%--25%	The power bank is full charged when all the light is lighting .
1	● ○ ○ ○	25%--50%	
2	● ● ○ ○	50%--75%	
3	● ● ● ○	75%--100%	
4	● ● ● ●	100%	

Charge the devices			
Display	Indicator light	Capacity percentage	Note
The first light flashes	○ ○ ○ ○	0%--25%	When the power is close to 5%, the last light flashes until power runs out
1	● ○ ○ ○	25%--50%	
2	● ● ○ ○	50%--75%	
3	● ● ● ○	75%--100%	
4	● ● ● ●	100%	

- Press the power button on the power bank to switch this on, and to determine the power bank's current capacity.
- During the power bank charging process, the capacity is displayed constantly.
- Each status LED corresponds to 25% of the capacity. The permanent illumination of an LED indicates that the capacity has already been reached. If three LEDs light up and the fourth one flashes, the power bank is at least 75% charged.
- If all four status LEDs light up, the full capacity is available.

### **Fast charging indicator**

- When you charge the power bank with a fast-charging cable, the green LED will light up and the power LED indicator will flash accordingly.
- When you charge the mobile phone with one of the integrated cables or a fast-charging cable, the green LED will light up and the power LED indicator will flash accordingly.

### **Charging instructions**

#### **Charge the power bank:**

- Connect the cable USB-A port to the charging device and the other end to the USB-C input connector of power bank.
- After connecting, the power bank is automatically charged and the current power level on the battery status indicator flashes. When the battery is fully charged, the status indicator light will be on.

#### **Charge digital equipment:**

- Use the integrated USB-C or Lightning charging cable to charge other applicable devices.
- Or connect your device to the USB-A port of the power bank using a compatible USB cable.
- After finishing the charging process, switch the power bank off, by pressing the power button twice. The status LEDs go out.
- If no device is connected, the power bank switches itself off automatically.

NOTE: In some cases, it might be required to press the power on button once.

EN

### **Cautions**

1. Please note that the external battery can achieve the best performance only after two to three times full charge cycles.
2. To extend the performance of the polymer battery, please, extend the charging time by up to 1-2 hours in the first three charge cycles.
3. Please do not attempt to disassemble or modify the product.
4. Please avoid physical damage to the product.
5. Please avoid using this product in the following environments: high temperature, low temperature, low pressure, humidity, dust, strong magnetic field, and long-term exposure to sunlight. We recommend using up to an altitude of 3000 meters, 0°C to 35°C and humidity 5-95%.
6. This product should not be exposed to drip and splashing with water.
7. Please, use a charging cable, specific to the product.
8. Please, comply with relevant local environmental regulations to remove the product and accessories.
9. Please, contact your local retailer or customer service center if you have any questions.

## Tips

1. If you do not use the power bank for a long time, we recommend you to fully charge the battery then place it in a dry environment with temperature range from 5 - 35 °C, please, avoid directly exposing the product in sunlight.
2. Please fully discharge then perform full recharging if you have not used the power bank for more than three weeks or the battery life of the product becomes shorter.

## Disposal and recycling information



The crossed-out wheeled-bin symbol on your product, battery, literature or packaging reminds you that all electronic products and batteries must be taken to separate waste collection points at the end of their working lives; they must not be disposed of in the normal waste stream with household garbage.

It is the responsibility of the user to dispose of the equipment using a designated collection point or service for separate recycling of waste electrical and electronic equipment (WEEE) and batteries according to local laws. Proper collection and recycling of your equipment helps ensure EEE waste is recycled in a manner that conserves valuable materials and protects human health and the environment, improper handling, accidental breakage, damage, and/or improper recycling at the end of its life may be harmful for health and environment.